

To remove and replace the IntelliC K H P Controller LCD Display module: