



MODEL FP0F360AC-09 REPAIR PARTS

Key No.	Part Description	Qty.
1	10-32x1-3/4 Phil. Hd Screw*	2
2	End Cover / Wear Plate	1
3	O-Ring	1
4	Impeller	1
5	Insert	1
6	U Cup Seal	1
7	Pump Body	1
8	Slinger	1
9	Motor**	1
10	Motor Brush and Spring Set	1 Pair

* Standard hardware item; purchase locally.

** If motor fails, replace entire pump.

Pump Head Assembly No. RP4940-22

includes Key Nos. 1 through 7.

Service Kit No. FP003414S-01

includes 1 each of Key Nos. 3, 4, and 6.