




SEWAGE PUMP MODEL CMV5



INSTALLATION AND OPERATION MANUAL

pentair.com

TABLE OF CONTENTS

INTRODUCTION

Safety Instructions..... 3

Installation..... 4

Repair Parts Index 6

Troubleshooting 7

Warranty..... 8

SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS: This manual contains important instructions that should be followed during installation, operation, and maintenance of the product. Carefully read and follow all safety instructions in this manual.

IMPORTANT SAFETY TERMINOLOGY



INSTALLATION

IMPORTANT INSTRUCTIONS BEFORE INSTALLATION

Failure to follow these instructions may cause serious bodily injury and/or property damage.



INSTALLATION





Figure 1: Typical Installation

REPAIR PARTS INDEX



2 ———

REPAIR PARTS LIST

REF. NO.	DESCRIPTION	PART NUMBER	QUANTITY
1	Electrical Cord, 20ft.	PW117-122-TSE	1
2	Tethered Piggyback Float Switch	PS17-111	1

WARRANTY

Warranty



AMERICAS
1101 Myers Parkway
Ashland, Ohio 44805
PH: 855-274-8947

CANADA
490 Pinebush Road,
Unit 4
Cambridge, Ontario,
Canada N1T 0A5
PH: 800-363-7867

pentair.com

All indicated Pentair trademarks and logos are property of Pentair. Third party registered and unregistered trademarks and logos are the property of their respective owners.

MY23833A314 (04-01-21) ©2021 Pentair. All Rights Reserved.