


# **MYERS**<sup>®</sup>

PUMP INSTALLATION AND SERVICE MANUAL

M118A System Sump Pump Hide-Away Basin Package

### MS33V10/M118A Hide-Away System Includes:

- MS33V10, 115V Atric
  Sberble SpPpn
- Pbythyen wherbw twcwyshedue
   40 PVC be ad
   invcheckal we



NOTE! TO THE INSTALLER: Please make sure you provide this manual to the owner of the

© 2016 Pentair plc. All Rights Reserved. MY1007 (07/21/16)

Thank you for purchasing your Myers® product. To help ensure years of trouble-free operation, please read the following manual carefully.

### **Before Operation:**

Read the following instructions carefully. Reasonable care and safe methods should be practiced. Check local codes and requirements before installation.

#### Attention:


This manual contains important

DO NOT cut off ground pin or use an adapter fitting. DO NOT use an extension cord. The pump power cord should be connected to a separately fused, grounded 115 volt line with a minimum capacity of 15 amps. NEVER touch the pump when it is connected to electrical power.

The receptacle should be located at least 4 feet above floor level. When wiring this pump follow all local electrical and safety codes and ordinances as well as the most recent National Electrical Code.

N.E.C., ANSI/NFPA 70 - 2001.

# 118A



Product		Warranty Period whichever occurs first:	
Jet <b>pen</b> l ce <b>f</b> gal <b>pbe</b> r elaedacce <b>e</b> s	bole pead		