

# SHURFLO

pentair.com

### SAFETY SYMBOLS

This is the safety alert symbol. When you see this symbol on your pump or in this manual, look for one of the following signal words and be alert to the potential for personal injury:

warns about hazards that will cause serious personal injury, a minimum diameter of 24" is recommended ause serious personal injury, death or major property damage if ignored.

warns about hazards that can cause serious personal injury, death or major property damage if ignored. Warns about hazards that will or can cause minor personal injury or property damage if ignored.

The word indicates special instructions that are important but not related to hazards.


#### CALIFORNIA PROPOSITION 65 WARNING:

This product and related accessories contain chemicals known to Tm[(t)3.4 (o Tm[(t)8.4 (o Tm[(t).8 US)BDC(n)8B.4 (o c)-16. s)-14.3 (n)407(6. s)-14.3 To-12.4 (m)-19.9 sItain cE6entain cE6entgeq6. e-19.9 (a)-13.0s47f

#### ADVANCED BILGE FEATURES

Anti-Airlock Tough Nylon Housing Tinned 6' Wire Assembly Water Cooled Motor Submersible Ignition Protected ISO 8846, ABYC, NMMA Type Accepted, CE

## INSTALLATION AND OPERATION





Remove ALL 7 screws for cleaning if necessary.

CONDITION	PROBABLE CAUSE
	Blown fuse. Wire connections. Impeller or float switch plugged with debris.
	Impeller/screen plugged with debris.



D AA i n