

SEDIMENT FILTRATION (0.5 MICRON) FOR PREMIUM QUALITY WATER FOR ICE APPLICATIONS

A LICA I N

Ice Machines

- High Capacity
- High olume
- High Flow

FEA E BENEFI

Effecti ely filters dirt and particles as small as 1/2 micron in size by mechanical means

Utilizes depth filtration and Fibredyne $^{\text{TM}}$ media for superior dirt-holding capability

NSF/ANSI Standard 53 certified to reduce cysts such as *Cryptosporidium* and *Giardia* by mechanical means

Lea es chlorine and chloramines within water that is supplied to equipment which helps to reduce slime growth in ice machine and ice bin

Choose a mounting location suitable to support the full weight of the system when operating.

Ne er use saddle al e for connection.

Use 3/4" water line.

Do not connect system to water-cooled condenser.

Install ertically with cartridges hanging down and allow 2^{r_2} " (6.35 cm) clearance